

Voice Changer™

Instructions for Use

Read through this entire instruction manual BEFORE using the **Voice Changer**. We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 1 year from the date of purchase.



For service claims or questions please consult our website ProtocolNY.com.

Battery installation (Figure below):

1. Unscrew and remove the battery cap.
2. Install 1 '9V' battery according to indicated polarities.
3. Replace the battery cap.



Operation:

1. Set the control panel to one of the below options:
Flip the switches up to turn them on.

A	B	C	D	E	Voice Effect
ON	ON	OFF	OFF	OFF	Low pitch
ON	OFF	OFF	OFF	OFF	High pitch
OFF	ON	OFF	OFF	OFF	Very low pitch
OFF	OFF	OFF	OFF	OFF	Very high pitch
OFF	OFF	OFF	ON	ON	Original+ robotic
ON	ON	OFF	OFF	ON	Low + robotic
OFF	OFF	ON	OFF	ON	High + robotic
OFF	OFF	OFF	OFF	ON	Very high + robotic
OFF	OFF	ON	OFF	OFF	Robotic male
OFF	OFF	ON	ON	OFF	Robotic female

2. Press the trigger and speak into the microphone.